

SANI SPORT / SANI DEFENX VE OPERATING MANUAL



510 Hodge, Saint Laurent, QC, H4N 2A4

Toll Free: 1-877-262-5801, Tel.: 514-382-1140, Fax: 514-382-8249

CONGRATULATIONS ON CHOOSING THE SANI SPORT / SANI DEFENX VE

The VE is a highly efficient and cost-effective way to successfully deodorize and reduce unwanted microorganisms present in enclosed spaces such as locker rooms, waiting areas, and offices.

Please keep this guide for future reference. Should you need a new copy, simply call 1-877-262-5801 or email marketing@sanisport.ca. You can also find a copy for download on our website.



Getting Started



Safety



Directions For Use



Additional Information



GETTING STARTED

GENERAL INFORMATION

The Sani Sport/Sani Defenx VE, referred to throughout this manual as the VE, is a proven delivery system for use with sanitizing and deodorizing solutions that are labeled and authorized for use in spray applications to reduce the presence of unwanted microorganisms where contamination can be a concern.* The high velocity distribution nozzle and cyclone fans provide an even spray in difficult to reach areas of the room. The VE also uses UV lights in a separate cycle to deliver ozone to the room and fully deodorize the space. The VE user should identify and select an EPA-authorized sanitizing solution that is labeled as suitable for use in spray applications. Certain sanitizing solutions that contain small concentrations of hydrogen peroxide have been authorized by EPA regulatory authorities for use in sprayable solutions and these may be compatible for use. However, you should always check the product label before selecting and using a product with the VE. Sani Sport team members may be able to assist you.

CLEANING AND CARING

The VE machine requires little maintenance. You may choose to wipe down the stainless-steel body with a damp rag from time to time. If the deodorizer and sanitizer solution tubes become clogged, please use compressed air to unclog the tubes. If you suspect that your machine is not working correctly or a part needs to be replaced, simply email marketing@sanisport.ca. A member of the Sani Sport team will call you to resolve your issue promptly. Alternatively, please call us at 1-877-262-5801.

MOBILITY

The VE comes with a travel case to ensure that it is properly protected in transport. The VE sits on 4 caster wheels, making it easy to maneuver in every situation. The dimensions of the VE are 30.5" deep X 11" wide x 24.25" high.



* Before using the VE apparatus, and any EPA-registered sanitizing solution and a deodorizing liquid to be used with the VE, be sure to read all product labels, warnings, and directions for use carefully. Do not operate the appliance when there are people in the room being treated. Wait one hour after the VE appliance operations have been completed before re-entering the room treated. The VE is intended as a supplement to enhance your facility's cleaning, housekeeping and hygiene practices.

SUPPLIES

Your VE is compatible for use with sanitizing and deodorizing solutions that are labeled for use in spray applications. Sani Sport personnel can assist you in identifying sanitizing and deodorizing solutions that are appropriate for use in spray applications. You will need to acquire these products separately. After you have located and obtained suitable sanitizing and deodorizing solutions, simply fill the empty 32 oz. reservoir for the sanitizing solution and the separate container for the deodorizing (neutralizing) solution. Then, simply insert the hose back into the bottles through the hole in the cap. Please note, the VE will spray approximately 1 oz. of a sanitizing solution during each hour of use. Please keep this in mind as you will need to independently identify and acquire additional quantities of these solutions when needed.

DEODORIZING AND SANITIZING TIPS

The VE will be most effective when addressing one room at a time. For best results, please close doorways to ensure that the VE can effectively treat the specific room in which it is placed. Leave the room and keep the door closed throughout the entire operation and for 60 minutes after the final cycle has been completed. The VE is compatible with common objects that ordinarily might be present in most rooms including, but not limited to:

- Desks
- Phones
- Chairs
- Lamps
- Light switches
- Door handles
- Floors
- Ceilings



SAFETY

Before operating this appliance, be sure to review these instructions and the labels of any products that you will be using with the VE to ensure compatibility and that you understand how to safely use the VE appliance and the any sanitizing and deodorizing solutions you acquire. Be sure to follow all label directions and do not operate the VE when there are people present in the room being treated.

The VE is manufactured at an EPA registered establishment.

Please note, the operator cannot be present in the room while the VE is operating. For your convenience, we have enclosed a color-coded wire. When affixed to the front of the machine, red

illumination indicates the cycle is running, green illumination indicates the cycle has ended. This system will help you determine when you can reenter the room. Simply place the other end of the wire under the door so you can see when the cycle is complete. Please wait 60 minutes after the entire cycle has been completed before entering the room.

You may also choose to run the VE at night to ensure no one enters the room during the cycle.



DIRECTIONS FOR USE

When selecting and obtaining suitable sanitizing and deodorizing solutions that are authorized and labeled for use in spray applications, be sure to read all of the products' labels to ensure compatibility and to be certain you understand how to safely use the solutions.

To deodorize and reduce the presence of unwanted microorganisms in an enclosed space: place the VE as close as possible to the center of the room. The VE is equipped with a high-level fan to help ensure the entire room gets treated. Be certain to fill the 32 oz. reservoir for the sanitizing solution. Also be certain to fill the separate container for the deodorizing (neutralizing) liquid. Then, simply insert the hose back in the bottles through the cap hole. Please note, the VE sprays approximately 1 oz. of a suitable sanitizing solution during each hour of use. The apparatus is designed to ensure treated surfaces remain wet for at least 30 seconds before air drying. Be certain the sanitizing solution you selected is EPA-registered and is compatible for use in spray application and in spaces with furniture and with equipment that will be found in the space to be treated and which readily air dry. Certain sanitizing solutions that contain small concentrations of hydrogen peroxide have been authorized by regulatory authorities for use in sprayable solutions and may be generally compatible for use. However, you should always check the product label and directions for use before selecting and using a product with the VE apparatus. Do not operate the VE when there are people present in the room being treated.

Before activating the apparatus, attach the enclosed color-coded indicator wire to the front of the machine; when the apparatus is running, the wire will display a red illumination that indicates the cycle is running and you should not reenter the room being treated. When green illumination appears, the cycle has ended. This system will help you determine when you can reenter the room. Simply place the other end of the color-coded wire under the door so you can see when the cycle is complete.

Turn the power switch to the ON position.

Select one of the preset cycles:

DESIGNATION	CYCLE TIME	ROOM SIZE
S	30 MINS	UNDER 600 SQ FT
M	60 MINS	600-1000 SQ FT
L	90 MINS	1000-1600 SQ FT

If the square footage exceeds 1600, simply use the + and – buttons to manually adjust the cycle time. The time increases or decreases in 10-minute intervals. The maximum cycle time is 240 minutes.

Once you have determined the appropriate cycle time, simply press the “cycle” button and promptly exit the room. The cycle will start immediately. Stay outside of the room being treated for at least 60 minutes following completion of the entire cycle.



Additional Information

Enclosed Unoccupied Spaces Suitable for VE Use

- Waiting areas
- Locker rooms
- Class rooms
- Offices
- And many more

Placing an Order

The VE is intended for use only with sanitizing and deodorizing solutions that are EPA-authorized and labeled for use in spray applications in the kinds of spaces that will be treated (e.g., athletic facilities, locker rooms and similar facilities where such equipment may be used and stored).